
THE
EXPERTS IN
FOODSERVICE
PROTECTION



KutGlove™ Cut Resistant Gloves WASHING INSTRUCTIONS

Recommended Frequency: Daily <u>or</u> as needed throughout the day Where: 3-compartment sink or washing machine / dryer



Inspect for excessive wear or damage. Discard immediately if damaged and replace.



Use warm soapy cloth or hand to clean all surfaces.



Thoroughly rinse / flush cleaning solution from all surfaces.



Sanitize all surfaces with sanitizing solution. Follow contact time recommended by manufacturer. Safety Station

| Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safety Station | Safet

Hang to dry on designated Safety Station to air dry overnight if not putting back into service immediately.

Important: Rinse any residual sanitizing solution from apparel / equipment if putting back into service.



WATCH VIDEO

For technical information contact
Tucker Safety Products, Inc at
800.786.7287 or visit us at

www.tuckersafetyproducts.com

ALTERNATIVE PROCEDURE



Machine wash with hot water and liquid detergent on regular setting.



Tumble dry on warm setting <u>or</u> allow to air dry separately on designated Safety Station.